



## A.V.Microtech

Address :-

Office:- 424D pocket-2 Mayur Vihar Phase-1, New Delhi 110091

Factory:- Sector 63 Noida

## Specification

1. Xbee adapter Board only (without Zigbee module).
2. Can configure Xbee board through X-CTU software.
3. Can be used as USB to Serial (TTL) adapter.
4. USB 5Volts powered.
5. Direct connection to PC USB port. No messy cables.
6. On board 3.3V regulator in DPAK package.
7. With FT232RL USB to UART.

## Circuit Diagram

